

Installation & Operating Instructions

Jukebox Paging Kit

Part No. 26679507

Introduction

These instructions provide installation and operating procedures for Rowe's Jukebox Wireless Paging Kit. This paging kit enables a jukebox to be used as a public-address system for making announcements via a microphone located up to 150 feet away. The kit can be added to any Rowe jukebox equipped with Rowe's standard 5 pin **Microphone Input** connector.

Installation Procedure

1. Turn power to the jukebox OFF.
2. Using the instructions supplied with the wireless microphone, install the battery in the microphone. Turn the receiver on (make sure the frequency of the microphone and receiver match).
3. Open the jukebox's front door and locate its **MICROPHONE INPUT** connector and **MUSIC LEVEL DURING PAGING** volume control. The latter may be found on the service mode screen. See jukebox manual for info.
4. Plug the 5 pin connector attached to the receiver into the **MICROPHONE INPUT** connector.
5. Turn power to the jukebox ON
6. Gradually turn the jukebox microphone **VOLUME** control UP while talking into the microphone with its switch set to ON. The receiver board led must be on. When the volume has been turned up sufficiently you should begin to hear your voice through the jukebox's speakers. Continue turning the control further clockwise until an appropriate microphone volume for paging is obtained.

CAUTION: If you encounter feedback (loud, unpleasant squealing sound) while setting paging volume, temporarily mute the microphone by setting it's switch off, and move it further away from the jukebox's speakers before resuming volume adjustment.



7. While playing music on the jukebox, adjust its **MUSIC LEVEL DURING PAGING** volume control for a suitable reduction in music loudness during paging to enable pages to be clearly heard above the music. This can be accomplished by repeatedly depressing then releasing the microphone's push-to-talk switch and comparing the normal music level to the reduced volume level when the switch is depressed.
8. Installation complete.

