

Installation Instructions

REPLACING POWER SUPPLY CBA 40923409 – Kit #26735501

These instructions outline the procedures to replace Power Supply CBA 40923409.

Tools Required

¼” nut driver.

Parts Included with this Kit:

<u>Item #</u>	<u>Part Number</u>	<u>Description</u>	<u>Quantity</u>
1	40923409	CBA-Power Supply w/Router Power	1
	26735550	These Instructions	

1. Turn off power to the jukebox
2. Unplug all connectors from the Power Supply 22145808 or 09, and remove Power Supply.
3. Remove 4 screws from the sides of the Power Supply, and remove the bottom cover.
4. Remove the 4 screws securing the CBA 40923408 or 09 to the chassis.
5. Remove all connectors from the CBA, and attach them to the new CBA.
Note: for the Power Supply 22145808, Plug the 10 pin Amp .156 connector into the 12 pin header at P1 on the CBA. Pins 1 and 2 of the 12 pin header will be open. The keys in the connector will align the connector properly. P7 of the CBA will be open.
6. Reverse above procedure to reassemble.